



## Tabella delle Frequenze/Canali per radiocomandi

(Evidenziati in giallo i canali AUTORIZZATI in Italia)

Banda dei 26-27 Mhz	
Canale	Frequenza
1	26,965
2	26,975
3	26,985
4	26,995
5	27,005
6	27,015
7	27,025
8	27,035
9	27,045
10	27,055
11	27,065
12	27,075
13	27,085
14	27,095
15	27,105
16	27,115
17	27,125
18	27,135
19	27,145
20	27,155
21	27,165
22	27,175
23	27,185
24	27,195
25	27,205
26	27,215
27	27,225
28	27,235
29	27,245
30	27,255
31	27,265
32	27,275

Banda dei 35 Mhz <small>In Italia riservata solo per aeromodelli</small>	
Canale	Frequenza
60	35,000
61	35,010
62	35,020
63	35,030
64	35,040
65	35,050
66	35,060
67	35,070
68	35,080
69	35,090
70	35,100
71	35,110
72	35,120
73	35,130
74	35,140
75	35,150
76	35,160
77	35,170
78	35,180
79	35,190
80	35,200
--	35,210
--	35,220

Banda dei 40 Mhz	
Canale	Frequenza
50	40,665
51	40,675
52	40,685
53	40,695
54	40,715
55	40,725
56	40,735
57	40,765
58	40,775
59	40,785
81	40,815
82	40,825
83	40,835
84	40,865
85	40,875
86	40,885
87	40,915
88	40,925
89	40,935
90	40,965
91	40,975
92	40,985

Banda dei 41 Mhz	
Canale	Frequenza
400	41,000
401	41,010
402	41,020
403	41,030
404	41,040
405	41,050
406	41,060
407	41,070
408	41,080
409	41,090
410	41,100
411	41,110
412	41,120
413	41,130
414	41,140
415	41,150
416	41,160
417	41,170
418	41,180
419	41,190
420	41,200

Banda dei 72 Mhz	
Canale	Frequenza
208	72,080
224	72,240